



# C Frame Stand Assembly Instructions



1. Locate the two leg pieces (A) and fit together as shown in **Figure 1**.
2. Insert a long bolt (F) through the bottom hole of the two leg pieces, and place a washer (H), and lock nut (E) on end of bolt, and tighten so nut is just on the bolt. **Figure 2**.
3. Place lower upright (B) onto leg assembly, and insert second long bolt (F) through upper hole in leg assembly and through aligned hole in lower upright piece. Attach washer (H) and lock nut (E). Now tighten both the lower and upper bolts securely using the wrench (J) and Allen wrench (K), as in **Figure 3**.
4. Place middle upright (C) onto lower upright, aligning holes as in **Figure 4**. Insert short bolts (G) with washers (H) into the two lower holes, and tighten using the Allen wrench (K) as in **Figure 5**.
5. Place the upper upright (D) onto the middle upright aligning holes as in **Figure 6**, Then insert short bolts (G) with washers (H) into the two upper holes and tighten securely using the Allen wrench (K) as in **Figure 7**.
6. Attach clip hook (I) to loop towards the top of upper upright as in **Figure 8**.
7. Attach your hanging chair to the stand by clipping the O-ring of the chair into the clip hook.

## CAUTION! Do Not Jump Or Bounce In The C-Frame Stand; Doing So May Cause Serious Injury

The C-frame has a maximum weight capacity of 275 lbs. Do not exceed maximum weight capacity. Always inspect hooks, hardware, and make sure bolts are tightened securely before each use. If hardware has become compromised in any way, do not use the product as it may be unsafe and using the stand could cause injury. Always inspect the overall condition of this product before each use. Never allow children to use the C-frame stand without adult supervision.

### Care Instructions:

For maximum life of this product, Algoma recommends putting the item indoors when not in use. Clean the frame using a mild soap and water, scrubbing when necessary. Dry with cloth.

